



MEMBRANE TIE-IN NOTES:

1. CLEAN SURFACE OF EXISTING MEMBRANE REMOVING ALL CONTAMINATES.
2. TREAT EXISTING MEMBRANE SURFACE WITH RAVEN 161 IN ACCORDANCE WITH PPG RECOMMENDATIONS.
3. REFER TO **TIE-IN AND OVERLAP PROCEDURE** DOCUMENTS FOR ADDITIONAL INFORMATION.



We protect and beautify the world®

TYPICAL DETAIL

BRIDGE DECK MEMBRANE TIE-IN

DWG NO.

M-4

REV.

1.1