



NOTES:

1. WHERE NEW MEMBRANE IS TO BE JOINED TO EXISTING MEMBRANE, THE NEW MEMBRANE SHALL OVERLAP THE EXISTING MEMBRANE BY AT LEAST 6".
2. DO NOT APPLY BD TOP COAT / AGGREGATE WITHIN 6" TIE-IN AREA.
3. IF AGGREGATE IS PRESENT IN SURFACE OF MEMBRANE WITHIN 6" TIE-IN AREA, REMOVE ALL AGGREGATE VIA MECHANICAL MEANS SUCH AS WIRE WHEEL, ETC. PRIOR TO OVERLAPPING NEW MEMBRANE ONTO EXISTING MEMBRANE.
4. OVERLAP AREA OF EXISTING MEMBRANE MUST BE TREATED WITH RAVEN 161 PRIOR TO PLACEMENT OF NEW MEMBRANE OVERLAP.
4. REFER TO **PPG HIGHWAY WATERPROOFING SYSTEM TIE-IN AND OVERLAP PROCEDURE** DOCUMENT FOR ADDITIONAL INFORMATION.



We protect and beautify the world®

TYPICAL DETAIL

BRIDGE DECK MEMBRANE LANE TIE-IN DETAIL

DWG NO.	M-5	REV.	1.1
---------	-----	------	-----